Handset Top S329

User Guide with SMS function

swisscom fixnet

Handset at a glance



1 **Display** in idle status
2 **Battery pack charge status**
(flat to full)
flashes: battery pack almost flat
flashes: battery pack charging
3 **Display keys** (page 9)
4 **Message key**
Access to calls and message lists (depending on the base station)
Flashes: new message or new call.
5 **End call key, On/Off key**
End call, cancel function, go back one menu level (press briefly), back to idle status (press and hold), activate/deactivate handset (press and hold in idle status)
6 **Hash key**
Key lock on/off (press and hold in idle status),
Toggle between upper/lower case and digits
7 **Swisscom Voice Portal" key** (page 10)
8 **Connection socket** for headset
9 **Microphone**
10 **Recall key**
- Confer (Flash)
- Insert a dialling pause (press and hold)
11 **Star key**
Ringtones on/off (press and hold),
Open table of special characters
12 **Key 1**
Select network mailbox (press and hold)
13 **Talk key**
Answer a call, open last number redial list (press briefly), start dialling (press and hold)
14 **Handsfree key**
Switch between earpiece and handsfree mode
Lights up: handsfree activated
Flashes: incoming call
15 **Control key** (page 8)
16 **Signal strength**
(high to low)
flashes: no reception

Note:
Illustration of a handset on a base station with SMS functionality.

Contents

Handset at a glance 1

Safety precautions 3

Top S329 – a handset with many extras 4

First Steps 4
Pack contents 4
Setting up the handset for use 4

Making calls 7
Making an external call 7
Ending a call 7
Answering a call 7
Handsfree operation 7
Muting 8
Making internal calls 8

Operating the handset 8
Switching the handset on/off 8
Activating/deactivating the keypad lock 8
Control key 8
Display keys 9
Returning to idle status 9
Menu guidance 9
Correcting incorrect entries 10

Using the directory and lists . . . 10
Directory 10
Last number redial list 12
Opening lists with the message key . 12

Using a handset as a room monitor 13
Activating the room monitor and entering the number to be called . . . 13

Handset settings 14
Changing the display language 14
Setting the display 14
Setting the screen picture 15
Setting display illumination 15
Activating/deactivating auto answer . 15
Adjusting the loudspeaker volume . . 15
Changing ringtones 16
Activating/deactivating advisory tones 16
Setting the alarm clock 17
Restoring the handset default settings 17

Appendix 18
Care 18
Contact with liquid 18
Questions and answers 18
Warranty/Maintenance/Repair/ Authorisation 19
Repair/Maintenance 19
Specifications 20

Notes on the operating instructions 20
Symbols used 20
Example: menu input 20
Example: multiple line input 21
Writing and editing a text message . . 22

Accessories 24

Index 25

Safety precautions

Caution:
Read the safety precautions and the user guide before use. Explain their contents to your children, and the potential hazards associated with using the phone.

Use only the mains adapter supplied, as indicated on the underside of the charging cradle.

Fit only the **recommended rechargeable battery pack** (page 20)! I.e. do not use any other battery type or non-rechargeable batteries as this could result in significant health risks and personal injury.

The operation of medical appliances may be affected. Be aware of the technical conditions in your particular environment (e.g. doctor's surgery).

The handset may cause an unpleasant humming noise in hearing aids.

Do not install the charging cradle in bathrooms or shower rooms. The charging cradle is not watertight (page 18).

Do not use your phone in environments with a potential explosion hazard (e.g. auto paint shops).

If you give your Top S329 to someone else, make sure you also give them the user guide.

Information about disposal

At the end of its service life this product must not be disposed of among the normal household refuse. Instead, it must be handed in at a sales outlet or at a collection point for recycling electrical and electronic devices in accordance with regulations governing the return, taking back and disposal of electrical and electronic devices (ORDEA).

The materials can be recycled as indicated. By recycling materials and reusing or utilising old appliances in any other way you are making an important contribution to the protection of the environment.

Note:
Not all of the functions described in this manual are available in all countries. The menu structure is dependent on the base station (analogue or ISDN base). The analogue version is represented in this user guide.

Top S329 – a handset with many extras

Your Top S329 not only lets you store up to 150 telephone numbers (page 10) - your Top S329 can do much, much more:

- You can designate important people as VIPs so you can tell important calls from the "tone" (page 11).
- You can store anniversaries (page 12) in your phone and it will remind you of them in advance.
- Select frequently used phone numbers at the press of a **single** key (page 11).

Have fun using your new Top S329!

First Steps

Pack contents

- one Top S329 handset,
- one charging cradle (incl. mains adapter),
- one battery pack,
- one battery cover,
- one lock ring,
- one belt clip,
- one headset socket cover,
- user guide (Ger, Fr, It),
- headset

Setting up the handset for use

Connecting up the charging cradle and mounting it on the wall (if required) is described at the end of these instructions.

Fitting the battery pack

Caution:
Use only the recommended rechargeable battery pack (page 20). I.e. on no account may a conventional (non-rechargeable) battery pack or other type of battery be used, as this may cause significant damage to health and property e.g. the outer casing of the battery or battery pack could be destroyed or the battery pack could explode. The phone could also malfunction or be damaged as a result of using batteries that are not of the recommended type.

- Fit the plug into the socket.
- Insert the battery pack.
- Place the cords in the cord routing.



Closing the battery cover

- Hold the battery cover at a slight angle and introduce the two lower lugs into the casing first. Then close the cover so that it clicks into place.



Locking the battery cover

Insert the catches on the lock ring or belt clip into the notches in the casing and make sure that the arrow markings on the casing are aligned with those on the bottom of the ring. Turn the lock ring or belt clip clockwise to the end stop. When both holes are horizontally aligned with the upper edge of the handset the lock ring is closed.



Opening the battery cover

Position both thumbs on the lock ring and at the same time turn the lock ring or belt clip anticlockwise and remove.



- Insert a coin into the cavity at the top of the battery cover and twist it until the cover opens.

Registering your phone

Before you can use your Top S329 you must register it to a base station. It can be registered to a maximum of four base stations. The actual registration procedure will depend on the type of base station.

Automatic registration

Important: The handset must not already be registered to any base station.

Registering the handset to the Top S329 base station occurs automatically. (On the E455 base station you register your handset manually, see page 6.)

- Place the handset in the base with its **display facing forward**.

Registration takes around 1 minute. During this process, **Regstr.Procedure** appears in the display and the name of the base station flashes e.g. **Base 1**. When the handset has registered, its screen displays its internal number, e.g. **INT 2** for internal number 2. The handset is assigned the lowest available internal number (1-6). If all internal numbers 1-6 have been assigned, number 6 is overwritten, pro-

vided the handset with the internal number 6 is in idle status.

Notes:
- Automatic registration is not possible when the base station on which you wish to register the handset is being used to make a call.
- Each key press interrupts the automatic registration.
- If automatic registration does not work, you will have to register the handset manually.

Manual registration

If the handset does not activate automatically when the battery pack is fitted, you must first charge the battery pack.

You must activate manual registration of the handset at both the handset and the base station.

After it has registered, the handset returns to idle status. The handset's internal number is shown in the display e.g. **INT 1**. If not, repeat the procedure.

1. On the handset

→ → **Handset** → **Register H/Set**

Select base station, e.g. **Base 1**, and press **OK**.

Enter the system PIN of the base station (the default is 0000) and press **OK**. The screen will display, e.g. **Base 1**.

2. On the base station

Within 60 secs. press and **hold** the registration/paging key on the base station (page 1) (approx. 3 secs.).

Headset socket

You can connect various types of headset (with jack connector).

If you do not connect a headset, please insert the cover supplied for the headset socket to guarantee the unit is still splash proof.

Charging the battery pack

- Plug the mains adapter of the charging cradle into a mains power socket.
- Place the handset in the cradle with its display facing forward.

To charge the battery pack, leave the handset in the charging cradle. If the handset is activated, the flashing battery icon in the top right of the display indicates that the battery pack is being charged. During handset operation, the battery icon indicates the charge status of the battery pack (page 1).

Initial charging and discharging of the battery pack

The correct charge status can only be displayed if the battery pack is first fully charged **and** discharged.

- To do this, leave the handset in the charging cradle **continuously** for **ten** hours. Your handset need not be switched on for it to charge.
- Afterwards, remove the handset from the charging cradle and do not put it back again until the battery pack is fully discharged.

Notes:
- The handset should only be placed in a base station or charging cradle that is designed for it.
- When the handset is in the cradle, it charges even if it is switched off.
- If the handset has switched itself off because the battery pack is flat and it is then placed in the cradle, it will switch itself on automatically.
- After the first battery charge **and** discharge you may replace your handset in the charging cradle after every call.

Please remember:

- Always repeat the charging and discharging procedure if you remove the battery pack from the handset and insert it again.

- The battery pack may warm up as it is charging. This is not dangerous.
- After a time the charge capacity of the battery pack will decrease for technical reasons.

Setting the date and time

If you have not yet set the date and time, press the display key **Time** to open the input field.

To change the time, open the input field via:

→ → **Date/Time**

▶ Change multiple line input:

Date:
Enter day, month and year in 6-digit format.

Time:
Enter hours and minutes with 4 digits, e.g. 0 + 7 pqrs 1 ␣ 5 jkl for 07:15 a.m.

Save Press the display key.

Changing the base station

If your handset is registered to more than one base station, you can set it to a particular base station or to the base station that has the best reception (**Best Base**).

→ → **Handset** → **Select Base**

Select one of the registered base stations or **Best Base** and press **OK**.

Making calls

Making an external call

External calls are calls using the public telephone network.

Enter the number and press the talk key.

Or:

Press and **hold** the talk key and then enter the number.

You can cancel the dialling operation with the end call key.

You are shown the duration of the call while the call is in progress.

Notes:
– Dialling with the directory or last number redial list (page 12) saves you repeatedly keying in phone numbers.

Ending a call

Press the end call key.

Answering a call

The handset indicates an incoming call in three ways: by ringing, by a display on the screen and by the flashing handsfree key.

You can accept the call by:

▶ Pressing the talk key.

▶ Pressing the handsfree key.

If the handset is in the charging cradle and the **Auto Answer** function is activated (page 15), the handset will take a call automatically when you lift it out of the cradle.

If the ringtone is intrusive, press the display key **Silence**. You can take the call so long as it is displayed on the screen.

Handsfree operation

In handsfree mode instead of holding the handset to your ear you can put it down e.g. on the table in front of you to allow others to participate in the call.

Activating/deactivating handsfree

Activating while dialling

Enter the number and press the handsfree key.

- You should inform your caller before you use the handsfree function so that they know someone else is listening.

Switching between earpiece and handsfree mode

Press the handsfree key.

Switch handsfree on or off during a call.

If you wish to place the handset in the charging cradle during a call:

- Press and hold the handsfree key while placing the handset in the base station. If handsfree key does not light up, press the key again.

For how to adjust the volume, see page 15.

Muting

You can deactivate the microphone in your handset during an external call. The other party hears a wait melody.

Press the control key on the left to mute the handset.

Press the display key to reactivate the microphone.

Making internal calls

Internal calls to other handsets registered on the same base station are free.

Calling a specific handset

Initiate internal call.

Enter the number of the handset.

Or:

Initiate internal call.

Select handset.

Press the talk key.

Calling all handsets ("group call")

Initiate internal call.

Press the star key. All handsets are called.

Ending a call

Press the end call key.

Operating the handset

Switching the handset on/off

Press and **hold** the end call key. You will hear the confirmation beep.

Activating/deactivating the keypad lock

Press and **hold** the hash key.

You will hear the confirmation beep. The icon appears in the display when the keypad lock is activated.

The keypad lock is deactivated automatically if someone calls you. It is re-activated when the call is finished.

Control key



In the following information the side of the control key (top, bottom, right, left) you have to press in each operating situation is shown in black (e.g. for "press the right of the control key").

The control key has a number of different functions:

When the handset is in idle status

Open the directory.

Open main menu.

Open list of handsets.

Set the ringtones on the handset (page 16).

In the main menu and in input fields

You can use the control key to move the cursor up, down, right or left.

In lists and submenus

Scroll up/down line by line.

Open submenu or confirm selection.

Go back one menu level, or cancel.

During an external call

Open the directory.

Initiate an internal consultation call.

Adjust loudspeaker volume for earpiece and handsfree mode.

Display keys

The function of the display keys changes depending on the particular operating situation. Example:



1 Current display key functions are shown in the bottom display line.
2 Display keys

Press the display key below to launch the function.

The most important display symbols are:

Menu Open the main menu.

Options Open a context-dependent menu.

C Delete key: backspace deletes one character at a time.

Go back one menu level or cancel operation.

Copy number into directory.

On bases with built-in answering machines: forward external call to answering machine.

Open the last number redial list (depending on the base station).

Returning to idle status

You can revert to idle status from anywhere in the menu as follows:

▶ Press and **hold** the end call key.

Or:

▶ Do not press any key: after 2 minutes the display will **automatically** revert to idle status.

Changes that you have not confirmed or saved by pressing **OK**, **Yes**, **Save**, **Send** or **Save Entry** **OK** will be lost.

An example of the display in idle status is shown on page 1.

Menu guidance

Your telephone's functions are accessed using a menu that has a number of levels.

Main menu (first menu level)

▶ Press with the handset in idle status to open the main menu.

The main menu functions are shown in the display as a list with icon and name.

Accessing a function, i.e. opening the corresponding submenu (next menu level):

▶ Navigate to the function using the control key. Press the display key **OK**.

Submenus

The functions in the submenus are displayed as lists.

To access a function:

▶ Scroll to the function with the control key ⊛ and press OK.

Or:

▶ Enter the corresponding digit combination.

A **short** press on the end call key ⌂ returns you to the previous menu level / cancels the operation.

Correcting incorrect entries

You can correct wrong characters in the text by navigating to the wrong input using the control key. You can then:

- press C to delete the character to the left of the cursor,
- insert characters to the left of the cursor,
- overwrite the character (flashing) when entering the time and date etc.
- **You will find examples of symbols used, menu entries and multiple line input in the appendix to this user guide, page 20.**

Using the directory and lists

You can store up to 150 entries altogether in the directory (the actual number depends on the size of the individual entries).

You can create a personalised directory for your own individual handset. You can, however, send the entries to other handsets or the base station (page 11).

Directory

In the **directory**, you can store numbers and the associated names.

▶ With the handset in idle status, open the directory by pressing the ⊛ key.

Length of entries

Number: max. 32 digits
Name: max. 16 characters

Note:
For quick access to a number from the directory (quick dial), you can assign the number to a key.

Storing a number in the directory

⊛ ➔ **New Entry**

▶ Change multiple line input:

Number :
Enter number.

Name :
Enter name.

Annivers.:
Enter anniversary if required (page 12).

Speed Dial:
Select key for quick dial.

▶ Save changes.

"Swisscom Voice Portal" key

⊡ Press the key.

Select **Swisscom VP** and confirm with OK. You will be connected straight to the Swisscom Voice Portal.

Note:
This key connects you to the Swisscom Voice Portal where you can activate additional services such as call diversion (Service 21, 61 or 67), call waiting (Service 43) or three-party conference with a simple voice command. You can also use voice command to access current sport, news and weather information.

Selecting entries in the directory

Open directory.

You have the following options:

- Use to scroll through the entries until the required name is selected.
- Enter the first character of the name, or scroll to the entry with if required.

Dialling with the directory

→ (select entry)

Press the talk key. The number is dialled.

Managing entries in the directory

→ (select entry)

Viewing an entry

View — Press the display key. The entry is displayed. Back with OK.

Editing entries

View Edit — Press display keys one after the other.

- Carry out changes and save.

Using other functions

→ (select entry) → Options (open menu)

The following functions can be selected with :

Display Number
Edit or add to a stored number. Then dial or call up further functions by pressing Options.

Edit Entry
Edit selected entry.

Delete Entry
Delete selected entry.

VIP Entry (directory only)
Mark a directory entry as **VIP** (Very Important Person) and assign it a particular ringtone. You can then identify VIP calls by their ringtones.

Requirement: caller display ("CLIP")

Copy Entry
Send a single entry to a handset (page 11).

Delete List
Delete **all** entries in the directory.

Copy List (depending on the receiving handset)
Send complete list to a handset (page 11).

Available Memory
Display the available entries in the directory (page 10).

Using quick dial keys

- Press and **hold** the required quick dial key.

Sending the directory to another handset

Requirements:

- The sending and receiving handsets must both be registered to the same base station.
- The other handset and base station can send and receive directory entries. Please read the relevant user guide for further information.

→ (select entry) → Options (open menu) → **Copy Entry** / **Copy List**

Enter the internal number of the receiving handset. You see **Copying entry**.

Yes / No — Press the display key.

A successful transfer is confirmed by a message and confirmation tone on the receiving handset.

Please remember:

- Entries with identical numbers are not overwritten on the receiving handset.
- The transfer is cancelled if the phone rings or if the memory of the receiving handset is full.

Storing anniversaries in the directory

You can store an anniversary for every number in the directory, and specify a time when you will receive a reminder call on the anniversary.

(Select entry; page 11)

View Edit — Press display keys one after the other.

Scroll to the Annivers.: line.

Edit — Press the display key.

▸ Change multiple line input:

Date:
Enter the day/month in 4-digit format.

Time:
Enter the hour/minute for the reminder call in 4-digit format.

Prompt:
Select the type of signal for the reminder and press OK.

▸ Save changes (page 21).

Note:
Reminder calls require a time stamp. If you select a visual signal, then a time stamp is not required and is automatically set to 00.00.

Deleting anniversaries

(Select entry; page 11)

View Edit — Press display keys one after the other.

Scroll to the Annivers.: line.

Edit Delete Save — Press display keys one after the other.

Reminder call on an anniversary

A reminder call is signalled on the handset using the selected ringtone.

Silence — Press the display key to stop the reminder call.

Last number redial list

The last number redial list contains the ten numbers last dialled with the handset (max. 32 numbers). If one of the numbers is in the directory, then the corresponding name will be displayed.

Manual last number redial

Press the key **briefly**.

Select entry.

Press the talk key again. The number is dialled.

When a name is displayed, you can display the corresponding phone number by pressing the display key View.

Managing entries in the last number redial list

Press the key **briefly**.

Select entry.

Options — Open the menu.

The following functions can be selected with :

Display Number (as in the directory, page 11)

Copy to Directory
Copy an entry to the directory (page 10).

Delete Entry (as in the directory, page 11)

Delete List (as in the directory, page 11)

Opening lists with the message key

An advisory tone sounds as soon as a **new entry** appears on a list. The key flashes (it goes off when the key is pressed). In idle status, the displays shows an icon for the new message.

If you press the key, you access the lists which contain new messages.

Using a handset as a room monitor

If the room monitor is activated, a previously stored destination number is called as soon as a set noise level is reached. You can store an internal or external number in your handset as the destination number.

The room monitor call to an external number stops after approx. 90 seconds. The room monitor call to an internal number (handset) stops after approx. 3 minutes (depending on the base station). While the room monitor is activated, all keys are locked except the end call key. The handset's speaker is muted.

When the room monitor is activated, incoming calls to the handset are indicated **without a ringtone** and are only shown on the screen. The display and keypad are not illuminated and advisory tones are also turned off.

If you accept an incoming call, the room monitor mode is suspended for the duration of the call, but the function **remains** activated.

If you switch off the handset, the room monitor mode is deactivated. You must reactivate the function after switching on the handset again.

Caution!

- **You should always check the operation of the room monitor before use. For example, test its sensitivity. Check the connection if you are diverting the room monitor to an outside number.**
- When the function is switched on, the handset's operating time is severely reduced. If necessary, place the handset in the charging cradle. This ensures that the battery pack does not run down.
- Ideally the handset should be positioned 1 to 2 metres away from the baby. The microphone must be directed towards the baby.
- The connection to which the room monitor is diverted must not be blocked by an activated answering machine.

Activating the room monitor and entering the number to be called

◉ → ★ → **Room Monitor**

▶ Change multiple line input:

Room M.:

Select **On** to activate.

Call to:

Press the display key **Edit** and enter destination number.

External number: select number from the directory or enter directly. Only **the last 4 digits** are displayed.

Internal number: delete any stored external number. **INT** ◉ (select handset or **Call All** , if all registered handsets are to be called) **OK**.

Store number with **Save Entry** **OK**.

Level:

Set noise level sensitivity (**Low** or **High**).

▶ Save changes (page 21).

The function is now activated. With ◉, you can move directly to settings.

Changing previously set external destination number

→ ★ → **Room Monitor**

Scroll to the **Call to:** line.

Edit Press the display key.

C Delete existing number.

- Enter number as described in "Activating the room monitor and entering the number to be called" (page 13).
- Save changes (page 21).

Changing previously set internal destination number

→ ★ → **Room Monitor**

Scroll to the **Call to:** line.

Edit Press the display key.

Yes Press the display key to confirm the prompt.

- Enter number as described in "Activating the room monitor and entering the number to be called" (page 13).
- Save changes (page 21).

Deactivating the room monitor remotely

Requirements: The phone must support touch tone dialling and the room monitor is set for an external destination number.

- Take the call from the room monitor and press keys 9 #.

The room monitor function will deactivate after the calls end. There will be no further room monitor calls. The other room monitor settings on the handset (e.g. no ringtone) will however remain activated until you press the display key **Off** on the handset.

To reactivate the room function with the same phone number:

- Turn on the activation again and save with **Save** (page 13).

Handset settings

Changing the display language

You can view the display texts in different languages (total of 17 languages).

→ → **Handset** → **Language**

The current language is indicated by ✓.

Select a language and press **OK**.

Press and **hold** (idle status).

If you accidentally choose a language you do not understand:

5 jkl 4 ghi 1

Press keys one after the other.

Select the correct language and press **OK**.

Setting the display

You have a choice of four colour schemes and several different contrasts.

→ → **Display**

Colour Scheme

Select and press **OK**.

Select a colour scheme and press **OK** (✓ = current colour).

Press **briefly**.

Contrast Select and press **OK**.

Select contrast.

Save Press the display key.

Press and **hold** (idle status).

Setting the screen picture

You can display a screen picture (picture or digital clock) when the handset is in idle status. This will replace the idle status display. It may conceal the date, time and name.

The screen picture is not displayed in certain situations, e.g. during a call or when the handset has been deregistered.

If a screen picture has been activated, the menu item **Screen Picture** is marked with ☑.

→ **Display** → **Screen Picture**

The current setting is displayed.

▸ Change multiple line input:

Activation:
Select **On** (screen picture is displayed) or **Off** (no screen picture).

Selection:
Change screen picture if necessary (see below).

▸ Save changes (page 21).

If the screen picture conceals the display, press the end call key briefly to show the idle display with time and date.

Changing the screen picture

→ **Display** → **Screen Picture**

Scroll to the **Selection** line.

View Press the display key. The active screen picture is displayed

Select **picture/Clock** and press **OK**.

▸ Save changes.

Setting display illumination

Depending on whether or not the handset is in the charging cradle you can set different levels of display illumination. If the charging cradle is switched on, the display is permanently dimmed.

→ **Display** → **Backlight**

The current setting is displayed.

▸ Change multiple line input:

In Charger
Select **On** or **Off** .

without Charger
Select **On** or **Off** .

Save Press the display key.

Press and **hold** (idle status).

Activating/deactivating auto answer

If you have activated this function, when you get a call you can simply lift the handset out of the charging cradle without having to press the talk key.

→ **Handset**

Auto Answer
Select and press **OK** (☑ = on).

Press and **hold** (idle status).

Adjusting the loudspeaker volume

You can set the loudspeaker volume for handsfree speaking to five different levels and the earpiece volume to three different levels. You can only make these adjustments during an external call.

The handsfree volume can only be adjusted when this function is set.

You are conducting an external call.

Open menu.

Select volume.

Save Press display key if necessary to save the setting permanently.

If is assigned a different function:

Options Open menu.

Volume Select and press **OK**.

Configure setting (see above).

Changing ringtones

- Volume:
  You can choose between five volumes (1–5; e.g. volume 2 = ▂▃□□□) and the "Crescendo" ring (6; volume increases with each ring = ▂▃▅▆▇).
- Ringtones:
  You can choose between 15 different melodies.

You can configure the following functions with different ringtones:

- **Ext. Calls** : For external calls
- **Internal Calls** : For internal calls
- **All**: The same for all functions

Settings for individual functions

Set the volume and melody depending on the type of signalling required.

◁▷▽△ → ✉ → **Audio Settings** → **Ringer Settings**

◁▷▽△ Setting, e.g. select **Ext. Calls** and press **OK**.

▸ Change multiple line input:

◁▷▽△ Set volume (1–6).

◁▷▽△ Scroll to the next line.

◁▷▽△ Select melody.

Save Press the display key to save the setting.

In idle status, you can also open the menu **Ringer Settings** by pressing ◁▷▽△ **briefly**.

Settings for all functions to ring the same

◁▷▽△ → ✉ → **Audio Settings** → **Ringer Settings** → **All**

▸ Set volume and ringtone (see "Settings for individual functions").

Yes Press the display key to confirm the prompt.

Press and **hold** (idle status).

Activating/deactivating the ringtone

Before answering a call or while your handset is in idle status, it is possible for you to cancel the ringtone permanently or for the current call. The ringtone cannot be re-activated while an external call is in progress.

Deactivating the ringtone permanently

*# △ Press the star key and hold until you can no longer hear the ringtone.

The 🔕 icon appears in the display.

Re-activating the ringtone

*# △ Press and **hold** the star key.

Deactivating the ringtone for the current call

Silence Press the display key.

Activating/deactivating the alert tone

In place of the ringer tone you can activate an alert tone. When you get a call, you will hear **a short tone** ("Beep") instead of the ringtone.

*# △ Press and **hold** the star key and **within 3 seconds:**

Beep on Press the display key. A call is now signalled by **one** brief alert tone. You will now see 🔔♫ in the display.

Activating/deactivating advisory tones

Your handset uses 'advisory tones' to tell you about different activities and statuses. The following advisory tones can be activated and deactivated independently of each other:

- **Key beep**: Each key press is acknowledged.

- **Acknowledge tones**:
  - **Confirmation tone** (rising tone sequence): at the end of the entry/ setting and when an SMS or a new entry arrives in the calls list
  - **Error beep** (descending tone sequence): when you make an incorrect entry
  - **Menu end tone**: when scrolling at the end of a menu
- **Battery low beep**: the battery pack requires charging.

→ → **Audio Settings** → **Advisory Tones**

▶ Change multiple line input:

Key Tones:
Select **On** or **Off** .

Confirm.:
Select **On** or **Off** .

Battery:
Select **On**, **Off** or **In Call**. The battery tone is activated/deactivated or only sounds during a call.

▶ Save changes (page 21).

You cannot deactivate the confirmation tone for placing the handset in the charging cradle.

Setting the alarm clock

Requirement: the date and time have already been set (page 7).

Activating/deactivating the alarm clock and setting the wake-up time

→

▶ Change multiple line input:

Alarm Clock:
Select **On** or **Off** .

Time:
Enter the wake-up time in 4-digit format.

Melody:
Select melody.

Volume:
Set the volume (1-6).

▶ Save changes (page 21).

You will see the icon.

A wake-up call with the selected ringer melody is signalled on the handset. The wake up call sounds for 60 seconds. The display shows **Alarm Clock** . If no key is pressed the wake-up call is repeated twice at five minute intervals and then switched off.

During a call, the wake-up call is signalled by a short tone.

Deactivating the wake-up call/ repeating after a pause (slumber mode)

Requirement: A wake-up call is sounding.

Off Press the display key. The wake-up call is deactivated.

or

Snooze Press the display key or any key. The wake-up call is deactivated and then repeated after 5 minutes. After the second repetition the wake-up call is deactivated completely.

Restoring the handset default settings

You can reset any individual settings and changes that you have made. This will not affect entries in the directory, call-by-call list or calls list, nor the handset's registration to the base station.

→ → **Handset** → **Reset Handset**

Yes Press the display key.

Press and **hold** (idle status).

Cancel the restoring process by pressing or the display key **No**.

Appendix

Care

- Wipe the charging cradle and the handset with a **damp** cloth (do not use solvent) or an antistatic cloth.

Never use a dry cloth. This can cause static.

Contact with liquid ⚠

Your handset is splash proof.

If it comes into contact with water, knock the water out of the microphone opening and remove any water on the handset with an absorbent cloth. Your handset is ready for use.

If your handset comes into contact with a larger amount of liquid take the following steps:

1. **Do not switch the handset on under any circumstances!**
2. Remove the battery pack immediately.
3. Remove the headset socket cover.
4. Hold the handset horizontally with the open battery compartment facing down.
5. Hold the handset vertically. Tilt the handset backwards and forwards slightly, giving it a gentle shake each time.
6. Dab all parts dry and then leave the handset for **at least 72 hours** with the battery compartment open and the keypad facing down in a dry, warm place (not: microwave, oven or similar).

When it has fully dried out, you will normally be able to use it again.

Questions and answers

Faults and Self-help with Troubleshooting

Not every fault is due to a defective phone. In certain circumstances, it can come from a brief interruption in the power supply to the base station (unplug/plug in power supply) or if the batteries of the handset are removed and inserted again. The following instructions should be of help for specific faults.

I**mportant:** problems or faults can only be remedied if you bring the complete unit (base station, handset, as well as connecting cable) to the place of purchase.

The display is blank.

1. The handset is not switched on.
   - Press and **hold** the end call key .
2. The batteries are flat.
   - Charge or replace the batteries (page 6).

The handset does not respond to a key press.

The keypad lock is activated.
- Press and **hold** the hash key (page 8).

"Base station x" flashes **in the display.**

1. The handset is outside the range of the base station.
   - Reduce the distance between handset/base station.
2. The handset has been de-registered.
   - Register the handset (page 5).

Base Search flashes in the display.

The handset is set for **Best Base** and no base station is switched on or within range.
- Reduce the distance between handset/base station.

Handset does not ring.

The ringtone is switched off.
- Activate the ringtone (page 16).

The other party cannot hear you.

You have pressed the (INT) key. The handset is "muted".
- Switch on the microphone again (page 8).

You hear an error tone when keying an input (a descending sequence of tones).

Action has failed/invalid input.

- Repeat the operation.
  Watch the display and refer to the operating instructions if necessary.

Warranty/Maintenance/Repair/ Authorisation

Warranty

The warranty period is 2 years as of the date of purchase.

For warranty repair, the warranty card, filled out and stamped by the place of purchase must be included with the defective device.

Excluded from the warranty are damages due to improper use, wear and tear, or tampering by others. The warranty does not include consumed materials and deficiencies which only affect the value or capability for use inconsiderably.

In case of an error, please contact your place of purchase.

Repair/Maintenance

Rental devices

If your phone does not operate properly, notify Technical Assistance (phone number 175).

The repair *) and the fault action are free of charge.

Purchased devices

Repair services are performed free of charge within the warranty period in accordance with the regulation of the warranty certificate). If a repair is necessary, the device must be returned to the place of purchase.

If Technical Assistance is made available (during the warranty period as well), the fault action is charged (route lump sum price as well as time expenses). The repair costs are additional outside the warranty period.

Batteries

Battery cells are considered consumed material, which is not covered by the warranty service. Defective batteries are not replaced free of charge. This applies to rental and purchased devices.

Help

If you have any general questions about products, services, etc., please contact your Swisscom Information Centre (toll-free number 0800 800 800).

Authorisation and Conformity

This device can be used throughout the European Economic Area inc. Switzerland.

Country-specific conditions have been taken into account. If you have any questions about the differences between the public phone networks, please contact your specialist dealer or network provider.

The CE mark attests to the phone's compliance with the essential requirements of the R&TTE directive.

Excerpt from the original declaration:
"The manufacturer declares, that the Top S329 is manufactured according to our Full Quality Assurance System certified by CETECOM ICT Services GmbH with ANNEX V of the R&TTE-Directive 99/5/EC. The presumption of conformity with the essential requirements regarding Council Directive 99/5/EC is ensured."
Senior Approvals Manager

The Declaration of Conformity (DoC) has been signed. In case of need, a copy of the original DoC can be made available via the company hotline.

CE 0682

The Declaration of Conformity can be found on the following web site:
www.swisscom.com under the rubric Online-Shop, Phone, Declaration of Conformity or can be ordered from the following postal address:

Swisscom Fixnet AG
Retail Business
Customer Premises Equipments (CPE)
3050 Bern

Specifications

Recommended battery pack

(Valid at the time of going to press)

Nickel-metal-hydride (NiMH):

V30145-K1310-X382

The handset is supplied with the recommended battery pack.

Handset operating times/charging times

Capacity	620 mAh
Standby time	Approx. 160 hours (6 days)
Calling time	Approx. 12 hours
Charging time	approx. 6 hours

The operating and charging times apply only when using the recommended battery pack.

General specifications

Handset dimensions	143 x 51 x 25 mm (L × W × H)
Weight of handset with battery pack	133 g

Notes on the operating instructions

This section explains the meaning of certain symbols and typographical conventions that are used in this user guide.

Symbols used

Copy Entry / **Copy List** (example)
Select one of the two menu functions specified.

Enter digits or letters.

Save
The display keys' current functions are shown reverse highlighted in the bottom display line.

Press the top or the bottom of the control key: scroll up or down.

Press the right or left of the control key: e.g. select setting.

/ 0 + / * △ etc.
Press the corresponding key on the handset.

Example: menu input

In the user guides, the steps you need to perform are shown in abbreviated form. This is illustrated below using the example of "Contrast". The things you have to do are explained in the boxes.

Example: multiple line input

There are many situations in which you can change the settings of a display or enter data in several lines.

In this user guide symbols are used to guide you step by step through multiple line input. This is illustrated below using the example of "Setting the date and time". The things you have to do are explained in the boxes.

You will see the following display (example):



Date:
Enter day, month and year in 6-digit format.

The second line is marked with [ ] to show it is active.

- Enter the date using the digit keys.

Time:
Enter hours/minutes in 4-digit format.

- Press the key.

The fourth line is marked with [ ] to show it is active.

- Enter the date using the digit keys.

- Save changes.

- Press the display key **Save**.
- Then press and **hold** the key.

The handset changes to idle status.

→ → **Display**

- With the handset in idle status, press on the right of the control key to open the main menu.
- Select the icon using the control key - press the control key at the top or bottom.

In the display header, **Settings** is displayed.

- Press the display key **OK** to confirm the function **Settings** .

The **Settings** submenu is displayed.

- Press the bottom of the control key repeatedly until **Display** is selected.
- Press the display key **OK** to confirm the selection.

Contrast Select and press **OK**.

- Press the bottom of the control key repeatedly until **Contrast** is selected.
- Press the display key **OK** to confirm the selection.

Select contrast and press **OK**.

- Press right or left on the control key to select the contrast.
- Press the display key **Save** to confirm the selection.

Press and **hold** (idle status).

- Press and hold the end call key until the handset returns to idle status.

Writing and editing a text message

The following rules apply when writing a text message:

- Control the cursor with ◁ ▷ △ ▽.
- Characters are added to the left of the cursor.
- Press the star key * to show the table of special characters.
- The first letter of the name of directory entries is automatically capitalised, followed by lower case letters.

Entering special characters

You can call up the table of special characters when writing an SMS using the * key. Select the required character and insert it with **Insert**.

Writing an SMS/name (without predictive text)

Requirement:
Your base station must support SMS.

Press and **hold** the hash key # to switch from "Abc" mode to "123" and from "123" to "abc" and from "abc" to "Abc" (upper case: 1st letter upper case, all others lower case). Press the hash key # **before** entering the letter.

The following applies when writing an SMS:

- The display shows whether upper case, lower case or digits is selected. "Abc", "abc" or "123" appears at the top right of the display.
- When you press a key and **hold** it, the characters of that key appear in the **bottom display line** and are highlighted one after the other. When you release the key the highlighted character is inserted into the input field.

Writing SMS (with predictive text)

Requirement:
Your base station must support SMS.

EATONI predictive text helps you when you are writing text messages.

Each key between 0 + and 9 wxyz is assigned several letters and characters. These appear in a selection line immediately under the text panel (above the display keys) as soon as you press a key. The letter you are most likely looking for is shown in reversed highlights and is at the beginning of the selection line. It is copied into the text panel.



1 EATONI is activated
2 Upper/lower case or digits
3 SMS text
4 Selection line

If this letter is the one you want, confirm it by pressing the next key. If it is not the one you want, **briefly** press the hash key # repeatedly until the required letter is reverse-highlighted on the display line and copied into the text panel.

If you press and **hold** the hash key # you switch from "Abc" mode to "123" and from "123" to "abc" and from "abc" to "Abc".

Deactivating/activating predictive text

Requirement: You are writing a text message.

Options Press the display key.

Predictive Text
Select and press **OK** (☑ = on).

Press the end call key **briefly** to return to the text panel. Enter the text.

Order of directory entries

The directory entries are usually sorted in alphabetical order. Spaces and digits take first priority. The sort order is as follows:

1. Space
2. Digits (0–9)
3. Letters (alphabetical)
4. Other characters

To get round the alphabetical order of the entries, insert a space or a digit in front of the name. These entries will then move to the beginning of the directory. Names which you have preceded with an asterisk will move to the end of the directory.

Accessories

All accessories and batteries are available from your mobile phone retailer.

Or you can order direct online via the online shop: www.siemens.com/shop.

The Online Shop also has the latest product information.

Only use original accessories. This will avoid possible health risks and damage to property, and also ensure that all the relevant regulations are complied with.

Index

A

Accessories 24
Acknowledge tones 17
Activating
  advisory tones 16
  call acceptance 15
  handset 8
  keypad lock 8
  room monitor 13
Adjusting
  loud speaker volume 15
Advisory tones 16
Alarm clock
  setting 17
Alert tone 16
Anniversary 12
  storing in directory 12
Answering a call 7
Auto answer 7, 15

B

Base station
  changing 7
Battery icon 6
Battery pack
  charging 6
  inserting 4
  recommended battery pack 20
Battery tone 17
Best base station 7

C

Call
  ending 7
  external 7
  internal 8
Call acceptance 15
Call duration 7
Call-by-call list 10
Calls list 12
Cancelling (operation) 9
Care, phone 18
Changing
  destination number 14
  display language 14
  ringtone 16
Character set, see Special characters . 22
Charge status display 6
Confirmation beep 17
Control key 1, 8
Correcting incorrect input 10
Customer Care 19

D

Deactivating
  handset 8
  keypad lock 8
Default settings
  handset 17, 18
Delete key 9
Deleting
  characters 10
Dialling pause
  entering 1
Digital clock 15
Directory 10
  managing entries 11
  opening 9
  order of entries 23
  saving entry 10
  sending entry/list to handset 11
  storing anniversary 12
Display
  changing display language 14
  contrast 14
  display keys 1, 9
  illumination 15
  in idle status 9
  memory 11
  screen picture 15
  setting 14
  wrong language 14

E

Earpiece mode 8
Earpiece volume 15
EATONI (predictive text) 22
End call key 1, 7
Ending a call 7
Entering special characters 22
Error beep 17
Example
  menu input 20
  multiple line entry 21

F

FAQs 18

G

Group call 8

H

Handset
- activating/deactivating 8
- advisory tones 16
- changing to best reception 7
- changing to different base station. . . 7
- contact with liquid 18
- display illumination 15
- display language 14
- idle status 9
- list. 9
- loudspeaker volume 15
- muting 8
- operating and charging times 20
- registering 5
- registering on another base station . . 7
- restoring default settings 17
- screen picture 15
- using room monitor 13

Handset charging times 20
Handset operating time 20
- in room monitor mode 13

Handsfree
- key 1

Handsfree talking 7
Hash key 1, 8
Headset socket 6
Hearing aids 3

I

Icon
- alarm clock 17
- ringtone 16

Idle status (display) 9
Idle status, returning to 9
Incorrect input (correction) 10
Internal call. 8

K

Key 1 (fast access) 1
Key click 16
Keypad lock. 8
Keys
- assigning directory entry 10
- cancel key 9
- control key. 1, 8
- delete key 9
- display keys. 1, 9
- end call key. 1, 7
- fast access 1
- handsfree key 1
- hash key 1, 8
- menu key 9
- message key 1
- On/Off key 1
- quick dial 10
- recall key 1
- star key. 1, 16
- Swisscom Voice Portal 1
- talk key. 1, 7

L

Language, display. 14
Last number redial list 12
Last number redial, manual 12
Liquid 18
List
- call-by-call list 10
- calls list 12
- handsets. 9
- last number redial list 12

Lock
- activating/deactivating keypad lock . 8

Loudspeaker volume. 15

M

Mains adapter 3
Making calls
- answering a call 7
- external 7
- internal. 8

Manual last number redial 12
Medical appliances 3
Memory
- directory. 11

Menu
- back one menu level 9
- end tone. 17
- key 9
- open. 9

Menu input 20
Message key. 1
- opening lists 12

Microphone 1
Multiple line entry 21
Muting handset 8

N

Number
- as destination for room monitor . . . 13
- saving in directory 10

O

On/Off key 1
Open
- menu 9

Opening
- directory 9

Order of entries in directory 23

P

Pack contents 4
Phoning
- internal 8

Predictive text 22

Q

Questions and answers 18
Quick dial 10, 11

R

Recall key 1
Registering (handset) 5
Reminder call 12
Reset 17
Ringtone
- changing 16
- setting melody 16
- setting volume 16

Room monitor 13
- activating 13
- entering destination number 13
- sensitivity 13

S

Safety precautions 3
Screen picture 15
Searching in directory 11
Sending
- directory entry to handset 11

Setting
- alarm clock 17
- date 7
- display illumination 15
- display language 14
- loud speaker volume 15
- ringtone volume 16
- screen picture 15
- time 7
- volume, melody 16

Setting melody 16
Setting the date 7
Setting the time 7
Settings, see Setting
Signal beep, see Advisory tones
Slumber mode 17
Sound
- ringtone 16

Specifications 20
Star key 1, 16
Swisscom Voice Portal
- key 1

T

Talk key 1, 7
Text
- writing, editing 22

Troubleshooting 18

V

VIP 11
Volume
- earpiece 15
- handset loudspeaker 15
- loudspeaker 15
- ringtone 16
- setting 16

W

Wait melody 8
Warning beep, see Advisory tones
Writing 22


26 mm
max. Ø 8 mm
max. Ø 4 mm
2x


6,5 mm


②
①